

SIMPLAIR A.E. TANK SUIT



RESPIREX™

Petrochemical Pharmaceutical

Type 2 'non gas tight' suit designed for use with breathable air supplied from an external compressed air source providing positive pressure.

- Air system completely contained within the suit that provides breathing and cooling air to the user
- An audible warning device designed to activate if the airflow drops below the minimum level required to maintain CO₂ below 1%
- Available in a range of chemical resistant fabrics
- An adjustable waist belt supports the air system and is fitted with a foam back pad for increased comfort
- Exhalation valves ensure that the pressure change within the suit does not exceed 400 pascals in one minute
- A wide, durable rigid PVC visor giving a high degree of undistorted vision
- Three point hanging system which helps prevent distortion during storage
- Heavy duty 122cm (48") long liquid tight zip, fitted vertically down the right hand side of the suit
- Cuff options: Locking cuff; Soft cuff; Double elasticated; Elasticated inner and straight outer; 'O' ring.
- Leg options: Double elasticated with stirrup or removable Kemblok™ boot
- Gloves that are compatible with the suit material
- A wide range of approved airline couplings can be fitted to the suit, however it is recommended that large bore couplings are used

Options

- Lifting eye
- Covers over exhalation valves

Specifications

Required Airflow: 360 l/m (12.71 cfm) (min) to 440 l/m (15.54 cfm) (max)

Sizing

	Small	Medium	Large	X-Large	XX-Large
Height (cm)	164-170	170-176	176-182	182-188	188-194
Chest (cm)	88-96	96-104	104-112	112-124	124-136

Air Supply

The air flowing into the garment must conform to EN 12021:1999 Annex A. In the event that partial contamination may exist in the factory ring main from which the suit draws its air supply, a Respirex in-line filter unit should be fitted to the air system; this will prevent the ingress of contamination down to 5 microns in size from entering the garment.

Protection



EN943-1:2002

Worn in conjunction with suitable gloves and safety boots the Simplair air supplied suit is CE marked to the requirements of TYPE 2 "Non Gas Tight" protective clothing

Specifications, configurations and colors are subject to change without notice.



www.respirexinternational.com
+44 (0)1737 778600
info@respirex.co.uk

Inquiries please contact:
Respirex North America
Ph: (281) 350-5001
Email: info@respirexna.com

Respirex International Limited
Unit F, Kingsfield Business Centre,
Philanthropic Road, Redhill, Surrey,
RH1 4DP, United Kingdom