

# SC1 REUSABLE SPLASH SUIT



RESPIREX™

Nuclear

Health  
Authorities

Petrochemical

Fire Brigades

Civil Resilience

The Respirex SC1 is a reusable Type 3 splash contamination suit designed for Self Contained Breathing Apparatus (SCBA) worn externally.

- One piece construction with integral hood incorporating a face seal that is both shaped and flexible, which provides a tight seal around the breathing apparatus face mask, preventing liquid penetration
- Horizontal 91cm (36") zip positioned across the rear shoulders of the garment with storm flaps secured by Velcro to prevent ingress of liquids. Can also be fitted with a gas tight zip for certain applications
- Double layer of material at the rear to prevent wear caused by the breathing apparatus rubbing against the suit
- Elasticated inner legs with stirrups with elasticated outer legs designed to accommodate safety boots of the user's choice
- Safety gloves compatible with the material of the suit, fitted by means of the Respirex locking cuff mechanism, or the Sure-Loc mechanism
- Available in a range of chemical resistant fabrics

## Options

- Reinforced knees and elbows
- Gas tight zip
- Self dress version with 122cm (48") gas tight zip fitted vertically down the right hand side of the suit
- Detachable Kemblok™ boots

## Materials

- Butyl
- Neoprene
- C2 PVC

## Sizing

	Small	Medium	Large	X-Large	XX-Large
Height (cm)	164-170	170-176	176-182	182-188	188-194
Chest (cm)	88-96	96-104	104-112	112-124	124-136

## Protection



**TYPE 3**  
EN466:1995



**EN463:1994**  
*When worn with appropriate boots and gloves*



**EN468:1993**  
*When worn with appropriate boots and gloves*

*Specifications, configurations and colors are subject to change without notice.*

