

NUPROTEX E PARTICULATE SUIT



RESPIREX™

Nuclear

Pharmaceutical

The Respirex Nuprotex E suit provides protection in atmospheres where particulate contamination may be a hazard to the body.

- Elasticated face seal suits a variety of respirator full face masks
- Designed to allow a full range of head movement that will not affect the seal between the suit and face mask
- Contoured upper body for ease of fitting and removal
- Double outer overlapping zip flaps
- Plain cuffs for tape sealing to safety gloves
- Plain ankles for tape sealing to safety boots

Approved Face Masks

- Avon N10
- Dräger Panorama Nova
- MSA Auer 3S
- Protector PPR2000 (Phantom Power Assisted Respirator)
- Scott Promask

Options

- Optional Welders version (300micron PVC suits only)

Specifications

Suit available in either anti-static 150 micron or 300 micron unsupported PVC. Anti-static properties are in accordance with EN1149-1:1996.

Sizing

	Small	Medium	Large	X-Large	XX-Large
Height (cm)	164-170	170-176	176-182	182-188	188-194
Chest (cm)	88-96	96-104	104-112	112-124	124-136

Protection



EN1073-2:2002

The suit provides a class 2 nominal protection factor for inward leakage according to EN1073-2:2002.



EN14605:2005

Type 4 (Spray Tight)

Protective clothing against liquid chemicals.

Specifications, configurations and colors are subject to change without notice.



Face Mask Seal, Side



Face Mask Seal, Top