

SUPPLIED-AIR RESPIRATOR HALF SUIT

NIOSH APPROVED BLOUSE



RESPIREX™

Petrochemical

Pharmaceutical

Respirex Supplied-Air respirators offer protection from airborne contaminants that are not immediately dangerous to life or health (IDLH). This product has Type C Continuous Flow Class NIOSH Approval No: TC-19C-327. Failure to use complete NIOSH Approved Respirex components and replacement parts voids approval of the entire assembly.

Features

- Three point hanging attachments
- Air distribution block with twin breathing hoses provides air to both sides of the hood
- An internal, adjustable waist belt supports the air system and is fitted with a foam back pad for increased comfort
- Respirex locking cuff system with reinforced cuffs
- Heavy duty open ended gas tight zip fitted from neck to waist
- Twin exhalation valves
- Can be used at between 12psi and 39psi (dependent on air supply hose length)
- A waist belt is fitted externally to provide a seal to the bottom of the blouse
- The air pigtail PVC yellow 3/8" bore hose terminates in a 1/4" male quick disconnect fitting (NIOSH Approved: Foster, Hanson, Schrader, Snap-Tite)

Specifications

Required Airflow: Can be used between 13 psi & 39 psi (dependent on air supply hose length)

Air Supply

This respirator must be supplied with clean, breathable air, Grade D or better, at all times. This respirator does not purify or filter out contaminants. See the product user's manual for additional details on operating and breathing air requirements.

Protection



Type C
Continuous Flow Class
NIOSH Approval No: TC-19C-378



Specifications, configurations and colors are subject to change without notice.

🌐: www.respirexinternational.com
☎: +44 (0)1737 778600
✉: info@respirex.co.uk

Inquiries please contact:
Respirex North America
Ph: (281) 350-5001
Email: info@respirexna.com

Respirex International Limited
Unit F, Kingsfield Business Centre,
Philanthropic Road, Redhill, Surrey,
RH1 4DP, United Kingdom