

HALF SUIT

TO BE WORN WITH A FACEMASK & EGRESS BOTTLE



RESPIREX™

Petrochemical

Pharmaceutical

The Respirex airline supplied Half Suit is constructed of orange neoprene material, with a rigid visor and outer disposable visor. The Half Suit's design includes expanded girth which accommodates most egress bottles.

Features

- Accommodates customers own NIOSH approved facemask, egress bottle and breathing air supply hose
- Three point hanging attachments
- Cooling halo attached to crown of hood (not for breathing air)
- Heavy duty open ended gas tight zip fitted from neck to waist
- A waist belt is fitted externally to provide a closure to the bottom of the Half Suit
- The cooling air pigtail terminates in a NPT

Options

- Full range of chemical resistant fabric
- A large pouch on the back to accommodate a standard breathing apparatus bottle (N.A. Part No. DSIMB011*)
- Available with or without cooling halo



Important Notes

This product, in all configurations, must be used with a NIOSH approved breathing apparatus facemask and bottle.

*Indicate Size: S = Small, M = Medium, L = Large, XL = X Large, XXL = XX Large, XXXL = XXX Large - Standard
Size: XXXXL = XXXX Large, XXXXXL = XXXXX Large - Special Order

Specifications, configurations and colors are subject to change without notice.

🌐: www.respirexinternational.com
☎: +44 (0)1737 778600
✉: info@respirex.co.uk

Inquiries please contact:
Respirex North America
Ph: (281) 350-5001
Email: info@respirexna.com

Respirex International Limited
Unit F, Kingsfield Business Centre,
Philanthropic Road, Redhill, Surrey,
RH1 4DP, United Kingdom