

DIELECTRIC HV3 MAXI OVERBOOTS



RESPIREX™

Power Generation

Power Distribution

Construction

Telecommunications

Transport

A **Class 3** electrically insulating dielectric overboot approved to current European standards. The Respirex Dielectric HV3 Maxi overboot is designed to be worn over safety boots and allows live working at up to 26.5kV with every boot tested at 30kV.

- Ingenious rear entry design ensures the boot is quick and easy to fit and remove
- Ideal for personnel who have to continually enter and exit hazardous areas
- Light weight
- Fluorescent green color
- Seamless construction
- Kick off lug
- REACH Compliant
- Slip resistance performance twice that required by SATRA TM144 standard

Care

- Machine washable at up to 40°C (104°F)
- Five year shelf life

Electrical Protection

Complete Boot: 30kV <18mA Leakage current
Max Working Voltage: 26.5kV

All boots are tested with AC as standard, DC testing is available on request.

Certification

Safety Footwear EN ISO 20347:2012 | SRC
Electrically Insulating Footwear EN 50321-1:2018 Class 3 AC
Personal Protective Equipment PPE Regulation (EU) 2016/425
Conforms to Dielectric Footwear ASTM F1117 (20kV)

Sizes

	Medium	Large	Extra-Large
US	7 - 9	10 - 12	13 - 15
UK	6 - 8	9 - 11	12 - 14
EU	39 - 42	43 - 45	46 - 49

Note: This overboot does not have a defined heel - if a defined heel is required for your application we recommend the Dielectric HV3+ safety boot.

Specifications, configurations and colors are subject to change without notice.



**CLASS 3
30kV
Protection**



For use with safety boots (safety boots not included)

