

AIR SUPPLY EQUIPMENT

AUTO-REWIND HOSE REEL & COMPRESSED AIRLINE HOSE



RESPIREX™

Auto-Rewind Hose Reel - NIOSH approved with Standard Yellow Hose

The Respirex automatic re-wind hose reel has been designed to provide a safe, convenient and efficient way to deploy air hose where required. Constructed in high impact UV stabilized polypropylene for all-purpose corrosion free durability, the hose reel can be installed indoors or out.

At an average weight of just 10 kg (22 lb) including hose, these reels are ideally suited for fixed position applications or for use as portable hose packs. All reels are supplied with hose ready for easy installation. A simple mounting bracket is included for wall or overhead positioning which allows the reel to swing through up to 270° or to be fixed centrally.

An equally simple optional bench or floor mount is also available. Both brackets feature a padlock facility to secure the reels in place. The automatic re-wind hose reel reduces the possibility of accidents and helps to improve the working environment. The user pulls out the length of hose required which is then automatically rewound after use. In addition to neat and tidy storage, the loose effort re-wind tension makes the automatic re-wind hose reel safe and easy to use even with the hose fully extended.

A two-position switch provides latching of hose at 0.5m intervals or a free run of hose for maximum convenience.

Standard Yellow Hose – NIOSH approved

Yellow reinforced PVC hose supplied in 25 feet and 50 feet lengths as standard, different lengths can be supplied if requested.

Bore size 9.5mm (3/8"), outside diameter 16mm.

Product Features

- All hoses have a working pressure of 10 Bar.
- Tested in accordance with EN14594
- All Respirex hoses and couplings are certified at 1,000 N. pull test and burst pressures of 30 Bar.
- All hose fittings are designed and manufactured by Respirex.
- All hoses are printed with CE marking information.
- NIOSH approved with Hanson, Schrader, Foster and Snap-Tite quick disconnect fittings.

Specifications, configurations and colours are subject to change without notice.

🌐: www.respirexinternational.com
☎: +44 (0)1737 778600
✉: info@respirex.co.uk

Inquiries please contact:
Respirex North America
Ph: (281) 350-5001
Email: info@respirexna.com



Heavy Duty Green PVC hose is available upon request.

Respirex International Limited
Unit F, Kingsfield Business Centre,
Philanthropic Road, Redhill, Surrey,
RH1 4DP, United Kingdom